




ELECTRIC COOKING TOP

Pos	Код	Описание
0001	MA1937400	ELECTRIC PLATE [C] 4000W
0002	CR0587230	SPACER [C] M8X13,5
0005	CR1095040	KNOB [C] SHAFT E15 D. 6
0006	MA9003088700	SPRING [C] KNOB
0007	CR0580460	BUSH [C]
0008	CR1095170	METAL LABEL [C] E15
0008	CR1095170	METAL LABEL [C] E15
0009	CR0588510	GASKET [C] CONTROL PANEL 900
0010	CR0588850	FLANGE [C]
0011	CR0587500	ORANGE PILOT LAMP [C]
0012	CR0587650	GASKET [C] SHAFT
0013	MA1616100	COMMUTATOR [C]
0013	MA1937800	COMMUTATOR [C] 250V
0014	MA1878400	TERMINAL BLOCK [C]
0015	CR0588170	6 POLES TERMINAL BLOCK [C] 450V
0015	MA20802799	TERMINAL [C] 6MM
0015	MA20806399	HANGER [C] TERMINAL
0015	MA20806499	ADESIVE SIGNAL L 1 8WA8 848-2AC
0015	MA20806599	ADESIVE SIGNAL L 2 8WA8 848-2AD
0015	MA20806699	ADESIVE SIGNAL L 3 8WA8 848 2AE
0015	MA20806899	ADESIVE SIGNAL 8WA8 848-2AA
0017	CR1166940	FLUE GRID [C] M60 ESSENCE 2015