





GAS PASTA COOKER

Pos.	Code	Previous code	Description	Notes	From:	To:
0001	CR0588001LE		SGOCCIOLATOIO CUOCIPASTA			
0002	CR0588190		PIN [C] DRAINER PASTA COOKER			
0003	CR0585951		PRESSURE SWITCH [C]	FORNIRE CON CR0731840		
0004	CR0585930		SILICONE RUBBER PIPE [C] D. 4X8			
0005	CR0796890		CLAMP [C]			
0006	CR1225320		CONNECTOR [C] M/F			
0007	CR0583521		PIPE [C] PASTA COOKER 900 TAP			
0008	CR0589882	CR0589881	PIPE [C]			
0009	MA1033504100		STEEL CLAMP [C]			
0010	CR1225330		COUPLING [C] TANK-PIPE CONNECTION			
0011	CR0588950		EXTENSION [C] DRAIN PASTA COOKER 900			
0012	CR0588950		EXTENSION [C] DRAIN PASTA COOKER 900			
0013	MA2863500		HANDLE [C] MF 63N			
0014	CR1220370R	CR1220370	SOLENOID VALVE [C] WATER	FORNIRE CON CR0586040		
0015	MA6086113		FOOT ASSEMBLY [C] H. 200			
0016	CR0681800		WATER DRAIN [C] TANK PASTA COOKER			



ELECTRIC PASTA COOKER

Pos.	Code	Previous code	Description	Notes	From:	To:
0001	BN8218100		HEATING ELEMENT [C] 7500W 230V SECP			
0002	MACM200100		GREASE [C]			
0003	MACM099200		GASKET [C] HEATING ELEMENT			
0004	MA15119299		GRAIN [C]			
0005	MACM021600		RING NUT [C]			
0006	MA52185099		KEY [C]			
0007	CR0581810		4 WAYS COMMUTATOR [C]			
0008	LA65080250		ENERGY REGULATOR [C]			
0009	CR0587650		GASKET [C] SHAFT			
0010	CR0588950		EXTENSION [C] DRAIN PASTA COOKER 900			
0011	CR0588510		GASKET [C] CONTROL PANEL 900			
0012	CR0798930		ASS. CRUSCOTTO CUOCIPASTA ELE 1100 M90			
0013	CR1095040		KNOB [C] SHAFT E15 D. 6			
0014	CR0580470		PLACCA NEUTRA COMANDI			
0015	CR1095240		METAL LABEL [C]P/CP SILKO E15			
0016	BN6A038507		GREEN PILOT LAMP [C]	COLORE VERDE		
0016	BN6A038907		RED PILOT LAMP [C]	COLORE ROSSO		
0016	BN6A039207		WHITE PILOT LAMP [C]	COLOREBIANCO		
0017	CR0582130		NUT [C]			
0018	CR0582140		GASKET [C]			
0019	CR0588170		6 POLES TERMINAL BLOCK [C] 450V			
0020	MA1037115100		FAIRLEAD [C] V-TEC PG16			
0021	MA1037115200		LOCK NUT [C]			
0022	MA1878400		TERMINAL BLOCK [C]			
0023	MACM187301	MACM187300	CONTACTOR [C]			
0025	CR0582120		HEATING ELEMENT BUSH [C] FOR PASTA COOKERS			