





descrParent

CERAMIC PLATE COOKING TOP

Pos	Code	Description
0002	CR0688620	GLASS CERAMIC PLATE [C]
0003	CR0411400	SILICONE [C]
0004	CR0688660	SQUARED ELECTRIC PLATE [C] 4KW 300X300
0004	CR0735670	ELECTRIC PLATE [C] 3,5KW 300X300 SQUARED
0005	MACM294000	SPRING [C] RADIANT ELEMENT - min. 10 pcs or multiples
0006	CR0587650	GASKET [C] SHAFT
0008	CR0682520	RED PILOT LAMP [C]
0009	CR1095040	KNOB [C] SHAFT E15 D. 6
0010	CR0581190	BUSH [C]
0011	CR1095170	METAL LABEL [C] E15
0012	CR0588510	GASKET [C] CONTROL PANEL 900
0013	CR0588950	EXTENSION [C] DRAIN PASTA COOKER 900
0014	CR0587500	ORANGE PILOT LAMP [C] Ø13,5MM 230V
0015	CR0688650	THERMOSTAT [C]

ELECTRIC STATIC OVEN



ELECTRIC STATIC OVEN

Pos	Code	Description
0001	CR0730790	SCHIENALE MONOBLOCCO M120 700
0002	CR0730550	ASS. SCARICO CONDENSA FORNO EL.700
0003	CR0681390	HEATING ELEMENT [C] OVEN 900
0004	MA1878500	THERMOSTAT [C] 360°C
0005	MA1309000	COMMUTATOR [C]
0006	MA1309115	THERMOSTAT [C] 0-300°C
0007	CR0587650	GASKET [C] SHAFT
0008	MA1037300910	ORANGE PILOT LAMP [C]
0009	CR0587930	CRUSCOTTO CUCINE GAS FORNO EL.M120
0010	CR0584020	METAL LABEL [C]
0011	CR1095040	KNOB [C] SHAFT E15 D. 6
0012	CR0581190	BUSH [C]
0013	CR1095130	METAL LABEL [C] FRY-TOP ELE. SILKO E15
0014	CR0588510	GASKET [C] CONTROL PANEL 900
0015	CR0588950	EXTENSION [C] DRAIN PASTA COOKER 900
0016	MACM041300	HINGE [C] FOR OVEN DOOR
0017	MA1304500	BRACKET [C] ROLLER HOLDER
0018	SI8200820R	DOOR [C] OVEN GN2/1 900
0020	CR0730210	SUPPORT [C] GRIDS OVEN 700
0021	CR0975150	BOTTOM [C]
0022	CR0581050	COVER [C] OVEN
0024	MA2306800	SHELF GRID [C] GN 2/1
0025	MA6086113	FOOT 1 3/4 INOX FLANG.H150
0026	MACM187301	CONTACTOR