



ТЕСТОМЕС HURAKAN HKN-20SN2V

Поз	Наименование детали	
1	top cover	37 circlip for shaft
2	sticker	38 motor pulley
3	start button	39 bearing
4	stop button	40 circlip for shaft
5	frame	41 circlip for shaft
6	foot	42 output gear
7	back cover	43 ratchet cover plate
8	motor	44 pin roller
9	gasket-large	45 roller pressure spring
10	spring washer	46 star weehl
11	hexagon bolts	47 out ring gear
12	flat key	48 ratचे cover plate
13	Small triangle belt pulley	49 flat key
14	gasket-large	50 flat key
15	spring washer	51 output
16	hexgon bolt	52 bearing
17	v-belt	53 seal ring
18	hexagon thin nut	54 seal ring
19	spring washer	55 Output shaft flange
20	flat washer	56 spiral
21	belt wheel-2	57 flat washer
22	bearing	58 spring washer
23	flat key	59 hexagon socket cap screws
24	input shaft	60 reducer cover
25	bearing	61 Bearing seat oil hole cover
26	bearing	62 hexagon socket cap screws
27	ratchet cover plate	63 spring washer
28	out ring gear	64 round pin
29	pin roller	65 round pin
30	roller pressuer spring	66 reducer box
31	star wheel	67 hex nut
32	ratchet cover plate	68 spring washer
33	bridge shaft pinion	69 flat washer
34	flat key	70 flat washer
35	bridge axis	71 hexagon bolts
36	bearing	72 Hexangular socket flat end set screw
		73 long pin
		74 circlip for shaft
		75 protective grid limited block
		76 Travel switch pressure wheel
		77 protective grid
		78 bowl
		79 lower shaft welder
		80 flat washer
		81 spring washer
		82 hex nut
		83 flat key
		84 bearing
		85 bearing
		86 circlip for shaft
		87 circlip for hole
		88 belt wheel-4
		89 flat washer
		90 spring washer
		91 hex nut
		92 hex nut
		93 spring washer
		94 flat key
		95 fixed rod
		96 flat washer
		97 hexagon bolts
		98 v-belt
		99 hex nut
		100 spring washer
		101 flat key
		102 belt wheel-2
		103 hexagon bolts
		104 gasket-large
		105 adjusting seat
		106 adjusting rod
		107 adjusting nut
		108 spring washer
		109 hex nut
		110 gasket-large
		111 flat washer
		112 spring washer
		113 hexagon bolts
		114 bearing
		115 flat key
		116 up and down drive shaft
		117 flat key
		118 belt wheel-1
		119 flat washer
		120 spring washer
		121 hex nut
		122 v-belt
		123 travel switch
		124 hex nut
		125 spring washer
		126 travel switch seat
		127 cross recess pan head screw
		128 overload protector
		129 power cord lock nut
		130 Connector bar
		131 a.c contactor
		132 auxiliary contact
		133 start capacitor
		134 working capacitor
		135 capacitance clip
		136 220V electric base plate